

Powerkit.68

MANUÁL

Instalaci Powerkit.68 pro HDR.68 se výkon navýší na více než 20 J. To závisí na různých faktorech, jako je venkovní teplota, CO2 a munice.

Držení tohoto příslušenství je v ČR legální. Instalace je však NA VAŠI ZODPOVĚDNOST.

POZOR: Jakmile bude na zbrani provedena technická změna, toto vede ke ztrátě záruky.

1. Otevřete kryt pistole tak, aby bylo vidět vnitřní fungování a je odnímatelný.
2. Opatrně otevřete vnitřek a vyjměte tlakové pouzdro. POZOR: Uvnitř jsou malé pružiny atd., které rády vyskakují.
3. Odstraňte pružinu a šroub z tlakové skříně.
4. Nyní můžete sejmout „zlatý“ uzávěr z tlakového pouzdra otevřeného a vyjměte "škrticí klapku" reduktoru.
5. "Zlaté" těsnící víčko musí být nasazeno zpět do tlakového pouzdra být použit. Redukční "škrticí klapka" by již neměla být instalována, jak bude ovlivnit výkon.
6. Nyní nastavte náš ladící ventil pomocí přiloženého šroubu ve spodní části tlakového pouzdra (malé vybrání nad kapslí CO2).
7. Potom vyměňte čep ventilu ve šroubu s naším ladícím čepem ven. Tip: Pro snadnější vyjmutí šroub předtím krátce zahřejte.
8. Nyní dejte pistoli zpět dohromady.

RPR SHOP

tel: 603 843 000, 604 213 838

www.rprshop.cz

www.rprgames.cz

www.rprhomedefence.cz

Powerkit.68

MANUAL

By installing the Powerkit.68 for the HDR.68, the performance increases to over 20 Joules. This depends on various factors such as outside temperature, CO2 and ammunition.

ATTENTION: As soon as a technical change has been made to the weapon, this leads to a loss of guarantee and warranty.

1. Open the cover of the gun so that the inner workings can be seen and is removable.
2. Carefully open the interior and remove the pressure housing. ATTENTION: Inside there are small springs etc., which like to jump out.
3. Remove the spring and bolt from the pressure housing.
4. Now you can remove the "golden" cap from the pressure housing open and take out the reducer "throttle".
5. The "golden" sealing cap must be put back into the pressure housing be used. The reducer "throttle" should no longer installed as this will affect performance.
6. Now set our tuning valve using the enclosed screw at the bottom of the pressure housing (small recess above the CO2 capsule).
7. Then swap the valve pin in the bolt with our tuning pin out. Tip: For easier removal, briefly heat the bolt beforehand.
8. Now put the gun back together.

RPR SHOP

tel: 603 843 000, 604 213 838

www.rprshop.cz

www.rprgames.cz

www.rprhomedefence.cz